

Monostand

SMOOTH 155 CLICK

GB Operating instruction

1. Combine the „Quick release plate“ with a Camera

- Attach (screw) the „Quick release plate“ to the camera



2. Mount the camera to the monopod

- Slide the camera with the plate into the monopod head
- To release the plate, push the fastener



3. Releasing of the quick release plate of the camera

- Press the unlocking fastener and turn the camera for a half turn anticlockwise; the release quick plate will be loosened
- Remove the camera with the release quick plate from the tripod head and unscrew the release quick plate from the camera



4. Expand the monopod leg to the desired height

- Extend the monopod by pulling out the leg segments
- The segments are locked automatically
- Push both release buttons at the monopod head and fold the monopod



5. Unfold the „feet“ of the monopod

- Pull down the feet until they click in
- Hold the button to fold the feet back up



6. Pull up the release button for rotating the monopod



1. Verbindung der Schnellwechselplatte mit der Kamera

- Befestigen (schrauben) Sie die Schnellwechselplatte an der Kamera



2. Montierung der Kamera am Einbeinstativ

- Schieben Sie die Kamera mit der Schnellwechselplatte in den Kopf des Einbeinstativs
- Drücken Sie auf den Verschluss um die Schnellwechselplatte wieder zu lösen



3. Lösen der Schnellwechselplatte von der Kamera

- Drücken Sie den Entriegelungsverschluss zusammen und drehen dabei die Kamera eine halbe Umdrehung gegen den Uhrzeigersinn, Schnellwechselplatte wird gelockert
- Kamera mit der Schnellwechselplatte aus dem Stativkopf herausnehmen und die Schnellwechselplatte von der Kamera abschrauben



4. Ausfahren des Einbeinstativs auf gewünschte Höhe

- Verlängern Sie das Einbeinstativ indem Sie die Beinsegmente herausziehen
- Die Segmente rasten automatisch ein
- Drücken Sie beide Auslöseknöpfe am Kopf des Einbeinstativs um die Beinsegmente wieder einzufahren



5. Ausklappen der Stativbeine

- Ziehen Sie die Beine nach unten bis sie einrasten
- Halten Sie den Knopf um die Beine wieder einzuklappen



6. Ziehen Sie die Hülle nach oben um das Einbeinstativ zu rotieren

